

Bioengineering 278: Magnetic Resonance Imaging Laboratory

Winter 2015

Lab 2

1. Generate an interferogram An interferogram (in the context of MRI) is an image in which two or more coherence pathways are present in the image and are allowed to interfere with one another. In this exercise, you will generate an interferogram between a spin echo and two FIDs (gradient echoes), one generated by the initial RF pulse, and one by the refocusing pulse. You will visualize the interference by applying a shim offset in the X direction. The shim offset should perturb the phase of the gradient echoes but not the spin echo. The shim offset will cause the spin echo and gradient echoes to interfere with one another in a spatially dependent manner. For this lab use the pink oil phantom in the 8 channel coil, and use the pulse sequence `spep_hcp`, which is a spiral pulse sequence that is homegrown. Prescribe a single slice axial spin echo sequence. The refocusing pulse is 90° phase shifted from the excitation pulse. Set CVs: `dda=4`, `reps=1`, `rf1type=1`, `fsat=0`, `pw_rf1=3200`, `pw_rf2=6400`, `cyc_rf1=2`, `cyc_rf2=2`, `slwid180=1`, `nl=32`, `opxres=128`, `optr=1s`. Set flip angles using: `ia_rf1=20479*flip1/90`, `ia_rf2=20479*flip2/180`. Prescan and scan using `flip1=90`, `flip2=180`, `te=30ms`, and verify that you get an image. This is the reference image.

- Calculate what combination of flip angles (`flip1` and `flip2`) will generate a spin echo and a gradient echo from `rf2` of equal amplitude (neglecting T1 decay). The solution may not be unique. **(5 points)**
- Adjust `ia_rf1` and `ia_rf2` to achieve these flip angles, and scan. The default crusher gradients around the refocusing pulse should destroy both FIDs, so you should only see the spin echo. Calculate the expected signal intensity relative to the reference image, scan, and compare your results with the predicted values. **(5 points)**
- Eliminate the effect of the crusher gradients by setting CV:`zcrush=-3.9`. Verify using the oscilloscope that the FID from `rf2` should not be crushed. Change the value of the X shim by 40 units, and rescan. From the spacing of the stripes, calculate the gain of the manual X shim adjustment (in G/cm per unit shim offset). **(5 points)**
- Calculate the expected profile across the stripes and compare with the acquired profile. **(5 points)**