

# Bioengineering 278


## Magnetic Resonance Imaging

Winter 2009  
Lecture 7

- RF Coils
  - MR signal detection
  - Reciprocity
  - Coil Q and Noise
  - Classes of RF coils
  - Coil Geometry
  - Coil Coupling

E. Wong, BE278, UCSD Winter 2009

## MR Signal Detection




Faraday's Law of Induction: 
$$\oint_C \mathbf{E} \cdot d\mathbf{l} = - \frac{d}{dt} \int_S \mathbf{B} \cdot d\mathbf{A}$$

E. Wong, BE278, UCSD Winter 2009

# Reciprocity

The spatial distribution the sensitivity of an RF coil is proportional to the field generated by a unit current flowing in the coil



If unit current  $I$  produces a transverse RF field  $B_1$ , then transverse magnetization  $M_{xy}$  induces:


$$\text{Voltage} \propto \int B_1(r) \cdot M_{xy}(r) dV$$

Note: Only transverse components of  $B_1$  and  $M$  count

For (a lot) more details, see: [http://coecs.ou.edu/Tamer.S.Ibrahim/Reciprocity\\_In\\_MRI.htm](http://coecs.ou.edu/Tamer.S.Ibrahim/Reciprocity_In_MRI.htm)


E. Wong, BE278, UCSD Winter 2009

## RF Coil Basics



$$Z = R + j\omega L$$


$$\sim (1 + 100j)\Omega$$



$$Z = \frac{j}{\frac{1}{\omega L - jR} - \omega C}$$



$$= \frac{\omega L - jR}{\omega CR}$$

$$\text{when } \omega = \sqrt{\frac{1}{LC}}$$




$$Z = \frac{A(R - j(A\omega C_1 - \omega L))}{R^2 + (A\omega C_1 - \omega L)^2} - \frac{j}{\omega C_2}$$

$$\text{where } A = R^2 + \omega^2 L^2$$



E. Wong, BE278, UCSD Winter 2009


# RF Coil Q



- Definition:  $Q = \# \text{ oscillations before amplitude} \rightarrow 1/e$ 
  - or:  $1/(\text{fractional energy loss per oscillation})$
- $Q(\text{spins}) = \omega_L T_2 \sim 10 \text{ million}$
- $Q(\text{coil+sample}) \sim 20\text{-}500$
- Therefore: spins **cannot** be closely coupled to coil
- So, what limits coil Q?

E. Wong, BE278, UCSD Winter 2009

## Coil losses and Sample losses



$$\frac{1}{Q_{total}} = \frac{1}{Q_{coil}} + \frac{1}{Q_{sample}}$$

- Sample losses are not from spins, but from random thermal motion of ions in sample
- Goal: minimize noise by minimizing losses
- Not much control over  $Q_{sample}$
- Try to get  $Q_{coil} \gg Q_{sample}$
- Maximize:  $\frac{B_1(ROI)}{\int |B_1| dV}$  (roughly)

E. Wong, BE278, UCSD Winter 2009





# Classes of RF coils

- \* Transmit Only: Used only to apply RF pulses - typically large with uniform  $B_1$
- \* Receive Only: Used only to receive RF signal - optimized for high sensitivity
- Transmit / Receive: Apply RF pulses and receive signal through same coil
- \* Multicoil Arrays: Typically Receive Only, used to increase sensitivity over large ROI, or to implement parallel imaging

\* These need active and/or passive T/R switching


E. Wong, BE278, UCSD Winter 2009

## RF Coil Geometries


- Surface Coil:  Where is  $B_z$ ?
- Quadrature Surface Coil: 
- Solenoid: 
- Birdcage Coil: 

E. Wong, BE278, UCSD Winter 2009


# RF Coil Coupling




$M \sim 1$



$M < 0$




$M = 0$



Coupling:

- Correlates Signal
- Correlates Noise
- In the limit, strongly coupled coils are one coil



**a**

**b**

TEM coil, Vaughan et al